

ENGLISH

References:

- A LEARNING FROM DEFAULT:** Learning the keyfob is performed in the Manager Menu of the Control Panel.
- B DELETING:** This deletes a keyfob from the control panel.
- C RE-LEARNING:** When a keyfob needs to be learned onto another control panel, with or without deleting the keyfob first, a 're-learn' must be performed instead of a 'learn'.
- D LEDs:** 1) **General LEDs:** (i) From power up: Not learnt (ii) Learning process. (iii) 8 x flashes: Learnt. (iv) Fast flashing: Unlocking. (v) Fast flashing: Locking. (vi) 18 x Slow flashes (10 secs): Fault with new battery installed. (vii) 6 x Flashes: Alarm (when checking status) 2) **Arming/Disarming LEDs:** (i) Arming. (ii) (Amber) 4 x Flashes: Fault, 1 x Flash: Key pressed. (iii) Armed. (iv) Disarmed.
- E REPLACING THE BATTERY:** When the battery needs replacing please make sure that the positive and negative as shown in the diagram.

Specification

Operation:

Button Configurations (all programmable):

Ⓜ, Ⓜ, I, II, Ⓜ+Ⓜ, I+II, Ⓜ+I, and Ⓜ+II.

Button Actions:

Show status, Arm/Set area, Disarm/Set area, Latch output, Timed output and Personal Attack.

Battery:

Battery: 1 x CR-1/3N Li-Mn Cell 3.0V (BATT-CR1/3N) .

Threshold: 2.1V +/- 5% at 25°C. **Life:** Up to 2 Years.

Wireless:

Transmission Frequency: 868MHz, FM Transceiver Narrow Band.

Transmission Method: Fully encrypted rolling code

Code combinations: 4294967295.

Materials and Environment

Indication: LEDs (Red, Green, Amber)

Temperature: Storage: -20°C to 50°C. Certified: -10°C to 40°C.

Nominal: -10°C to 50°C.

Dimensions (H x W x D): 72 x 30 x 20mm. Weight: 28g

Compatible with the Enforcer, PCX and EURO commercial control panels (using the Wireless Expander).

Battery Information



The battery supplied has been chosen to provide long service life whilst, for safety reasons, having limited output current. When disposing of the product, the battery must be removed and disposed of separately in accordance with the local regulations.

Product Information

For electrical products sold within the European Community. At the end of the electrical products life, it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country. To prevent possible damage to components, any static charge on your body needs to be eliminated before touching the inside of the unit. This can be accomplished by touching some grounded/earthed metallic conductor such as a radiator/pipework immediately before replacing the battery.

Warranty

This product is sold subject to our standard warranty conditions and is warranted against defects in workmanship for a period of two years (battery excluded). In the interest of continuing care and design, Pyronix Ltd reserves the right to amend specifications, without giving prior notice. Please see the control panels programming manuals for further information.

A LEARNING FROM DEFAULT

| UK | EXPORT | ITALIAN |
|---------------------|----------------------------------|-----------------------------------|
| CHANGE CODES? | LEARN USER CODES KEYFOBS & TAGS? | MEMORIZZA CODICI TAG/TELECOMANDI? |
| Add New User? | User Codes/Tass/Learn Keyfobs? | Memorizza Codici Tas/Telecomandi? |
| Empty [01] | Empty [01] | Vuoto [01] |
| Enter User Code [] | Enter User Code [] | Memorizza [] |

| ITALIAN |
|------------------------|
| Nome Utente |
| - |
| Scegli Tasto Tasto [1] |
| Funzione: [2] |
| Ins.re Area |

| UK/EXPORT |
|---------------------------|
| User Name |
| - |
| Select Button Lock [1] |
| Button Action[2] Set Area |

B DELETING

| UK | EXPORT | ITALIAN |
|-------------------------|----------------------------------|-----------------------------------|
| CHANGE CODES? | LEARN USER CODES KEYFOBS & TAGS? | MEMORIZZA CODICI TAG/TELECOMANDI? |
| Add New User? | User Codes/Tass/Learn Keyfobs? | Memorizza Codici Tas/Telecomandi? |
| Delete/Change User? | Keyfob [01] | Telecomando [01] |
| Delete User? | Enter User Code [*****] | Memorizza [*****] |
| Keyfob [01] | C | C |
| Enter User Code [*****] | Enter User Code [] | Memorizza [] |
| C | | |
| Enter User Code [] | | |

C RE-LEARNING

| UK | EXPORT | ITALIAN |
|-------------------------|----------------------------------|-----------------------------------|
| CHANGE CODES? | LEARN USER CODES KEYFOBS & TAGS? | MEMORIZZA CODICI TAG/TELECOMANDI? |
| Add New User? | User Codes/Tass/Learn Keyfobs? | Memorizza Codici Tas/Telecomandi? |
| Delete/Change User? | Keyfob [01] | Telecomando [01] |
| Delete User? | Enter User Code [*****] | Memorizza [*****] |
| Keyfob [01] | C | C |
| Enter User Code [*****] | Enter User Code [] | Memorizza [] |
| C | | |
| Enter User Code [] | | |

E REPLACING THE BATTERY

| 2) Arming/Disarming LEDs |
|--|
| (i) Arming |
| (ii) (Amber) 4 x Flashes: Fault 1 x Flash: Key pressed |
| (iii) Armed |
| (iv) Disarmed |

